

L PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Magnetic Clutch and Lock Sensor	90980-10942	D 5	Door Lock Control SW	90980-10964
A 2	ABS Speed Sensor Rear LH	90980-11002	D 6	Door Courtesy SW LH	90980-10871
A 3	ABS Speed Sensor Rear RH		D 7	Door Courtesy SW RH	
A 4	A/C SW	90980-11911	D 8	Door Lock Motor, Door Key Lock and Unlock SW and Door Unlock Detection SW LH	90980-11858
A 5	A/C Thermistor	90980-11918			
A 8	Airbag Squib (Passenger's Airbag Assembly)	90980-11886	D 9	Door Lock Motor, Door Key Lock and Unlock SW and Door Unlock Detection SW RH	90980-11858
A 9	Airbag Squib (Steering Wheel Pad)				
A10	A/C Condenser Fan Motor	90980-11410	D10	Diode (Idle-Up)	90980-11071
A11	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	90980-10943	E 1	Engine Coolant Temp. Sensor	90980-10737
A14	ABS Speed Sensor Front LH	90980-11003	E 2	Engine Control Module	90980-11638
A15	ABS Speed Sensor Front RH	90980-11074	E 3	Engine Control Module	90980-11637
A16	Auto Antenna Motor	90980-11003	E 4	Engine Control Module	90980-11476
A17	Auto Antenna Relay	90980-10799	E 5	Engine Control Module	90980-11421
A18	Accel Position Sensor	90980-11150	F 1	Front Airbag Sensor LH	90980-11856
B 1	Back-Up Light SW (M/T)	90980-11051	F 2	Front Airbag Sensor RH	
	Back-Up Light SW (Sequential Manual Transmission)	90980-11250	F 3	Front Door Speaker LH	90980-10935
B 2	Blower Motor	90980-10214	F 4	Front Door Speaker RH	
B 3	Blower Resistor	90980-10171	F 5	Front Parking Light LH	90980-11162
B 4	Blower SW	90980-10877	F 6	Front Parking Light RH	
B 5	Body ECU	90980-11877	F 7	Front Side Marker Light LH	90980-11074
B 6	Body ECU	90980-10819	F 8	Front Side Marker Light RH	
B 7	Buckle SW and Tension Reducer LH	90980-10795	F 9	Front Turn Signal Light LH	90980-11019
B 8	Buckle SW RH and Occupant Detection Sensor	90980-10860	F10	Front Turn Signal Light RH	
B 9	Brake Fluid Level Warning SW	90980-11207	F11	Front Wiper Motor	90980-11599
B10	Back-Up Light SW No.2	90980-11250	F12	Fuel Pump and Fuel Sender	90980-11077
C 1	Camshaft Position Sensor	90980-10947	F13	Front Fog Light LH	90980-11660
C 2	Camshaft Timing Oil Control Valve	90980-11162	F14	Front Fog Light RH	
C 3	Crankshaft Position Sensor	90980-10947	F15	Front Fog Light SW	90980-10799
C 4	Center Airbag Sensor Assembly	90980-11869	G 1	Generator	90980-11349
C 5	Center Airbag Sensor Assembly	90980-11872	G 2	Generator	90980-09200
C 6	Center Airbag Sensor Assembly	90980-11867	G 3	Gear Shift Actuator	90980-10988
C 7	Cigarette Lighter	90980-10760	G 4	Gear Shift Actuator	90980-10942
C 8	Clock	90980-11013	G 5	Gear Shift Actuator	90980-11034
C 9	Clutch Start SW	90980-10825	H 1	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-11028
C10	Combination Meter	90980-11915	H 2	Heated Oxygen Sensor (Bank 1 Sensor 2)	
C11	Combination Meter	90980-11913	H 3	Heated Oxygen Sensor (Bank 2 Sensor 1)	
C12	Combination Meter	90980-11923	H 4	High Mounted Stop Light	90980-11002
C13	Combination SW	90980-11986	H 5	Hazard SW	90980-10801
C14	Combination SW	90980-11672	H 8	Horn LH	90980-10619
C15	Combination SW	90980-11594	H 9	Horn RH	
D 1	Data Link Connector 3	90980-11665	H10	Hydraulic Power Unit	90980-11240
D 2	Daytime Running Light Relay	90980-12034	H11	Headlight LH (High)	90980-11659
D 3	Diode (Door Courtesy)	90980-10962	H12	Headlight LH (Low)	90980-10481
			H13	Headlight RH (High)	90980-11659
D 4	Diode (DRL)		H14	Headlight RH (Low)	90980-10481
			I 1	Idle Air Control Valve	90980-11145

Note: Not all of the above part numbers of the connector are established for the supply.

Code	Part Name	Part Number	Code	Part Name	Part Number
I 2	Ignition Coil and Igniter No.1	90980-11885	R 4	Radio and Player	90980-10996
I 3	Ignition Coil and Igniter No.2		R 5	Rear Window Defogger Relay	82660-20340
I 4	Ignition Coil and Igniter No.3		R 6	Rheostat	90980-11165
I 5	Ignition Coil and Igniter No.4		R 7	Remote Control Mirror SW	90980-11657
I 6	Injector No.1	90980-11875	R 8	Radiator Fan Motor	90980-10928
I 7	Injector No.2		R 9	Rear Window Defogger	90980-10825
I 8	Injector No.3		R10	Remote Control Mirror LH	90980-10907
I 9	Injector No.4		R11	Remote Control Mirror RH	
I10	Ignition SW	90980-11778	S 1	Starter	90980-09506
I11	Interior Light	90980-11724	S 2	Starter	90980-11400
J 1	Junction Connector	90980-11398	S 3	Short Connector (SRS No.1)	90980-11023
J 3	Junction Connector	90980-11661	S 4	Short Connector (SRS No.1)	90980-10904
J 4	Junction Connector		S 5	Short Connector (SRS No.2)	90980-10871
J 5	Junction Connector (M/T)	90980-11542	S 6	Short Connector (SRS No.2)	90980-10870
	Junction Connector (Sequential Manual Transmission)	90980-11529	S 7	Stop Light SW	90980-11118
J 6	Junction Connector	90980-11398	S 8	Short Connector (Rear Window Defogger)	90980-10915
J 7	Junction Connector	90980-10897	S 9	Short Connector (Rear Window Defogger)	90980-10916
K 1	Knock Sensor	90980-11166	S10	Shift Lever Position Sensor	90980-11923
L 1	License Plate Light LH	90980-11002	S11	Shift Lock Control ECU	90980-10795
L 2	License Plate Light RH		S12	Skid Control ECU with Actuator	90980-12020
M 1	Mass Air Flow Meter	90980-11317	T 1	Throttle Position Sensor (M/T)	90980-11261
N 1	Noise Filter (Ignition)	90980-10843		Throttle Position Sensor (Sequential Manual Transmission)	90980-10711
N 2	Noise Filter (Rear Window Defogger)	90980-10825	T 2	Transponder Key Amplifier	90980-11909
N 3	Neutral Start SW	90980-11025	T 3	Turn Signal Flasher Relay	90980-10704
O 1	Oil Pressure SW	90980-11363	T 4	Tension Reducer Solenoid LH	90980-10825
P 1	Parking Brake SW	90980-10871	T 5	Tweeter LH	90980-10916
P 2	Passenger Airbag Manual ON/OFF SW	90980-11013	T 6	Tweeter RH	
P 3	Passenger Airbag Manual ON/OFF SW	90980-12017	T 7	Throttle Control Motor	90980-10942
P 4	Power Window Control SW LH	90980-10797	T 8	Transmission Revolution Sensor	90980-11075
P 5	Power Window Control SW RH	90980-10789	T 9	Transmission Control ECU	82824-17020
P 6	Power Steering ECU	90980-12068	U 1	Unlock Warning SW	90980-10860
P 7	Power Steering ECU	90980-10897	V 1	VSV (Canister Closed Valve)	90980-11162
P 8	Power Steering ECU	90980-10942	V 2	VSV (EVAP)	90980-11156
P 9	Power Window Motor LH	90980-10860	V 3	Vapor Pressure Sensor	90980-11143
P10	Power Window Motor RH		V 4	VSV (Pressure Switching Valve)	90980-11156
P11	Pretensioner LH	90980-11886	W 1	Window Lock SW	90980-10997
P12	Pretensioner RH		W 2	Washer Motor	90980-10981
R 1	Rear Combination Light LH	90980-10988	Z 1	Option Connector (TVIP)	90980-10871
R 2	Rear Combination Light RH		Z 2	Option Connector (TVIP Siren)	90980-11051
R 3	Radio and Player	90980-10997			