


<b>Last Modified:</b> 6-2-2008	5.1 A	<b>From:</b> 200601
<b>Model Year:</b> 2007	<b>Model:</b> Camry	<b>Doc ID:</b> RM0000022NT001X
<b>Title:</b> 2GR-FE ENGINE CONTROL SYSTEM: ECM: REMOVAL (2007 Camry)		


## REMOVAL

1. REMOVE WINDSHIELD WIPER ARM AND BLADE ASSEMBLY LH [INFO](#)
2. REMOVE WINDSHIELD WIPER ARM AND BLADE ASSEMBLY RH [INFO](#)
3. REMOVE FRONT FENDER TO COWL SIDE SEAL LH [INFO](#)
4. REMOVE FRONT FENDER TO COWL SIDE SEAL RH [INFO](#)
5. REMOVE COWL TOP VENTILATOR LOUVER SUB-ASSEMBLY [INFO](#)
6. REMOVE WINDSHIELD WIPER MOTOR AND LINK [INFO](#)
7. REMOVE COWL TOP OUTER PANEL SUB-ASSEMBLY [INFO](#)
8. REMOVE ECM



(a) Remove the 3 nuts.

(b) Disconnect the 2 ECM connectors and remove the ECM.



- (1) Raise the 2 levers while pushing the locks on the 2 levers, and disconnect the 2 ECM connectors.

**After disconnecting the connector, make sure that dirt, water and other foreign matter do not contact the connecting part of the connector.**

