

<b>Last Modified:</b> 6-2-2008	5.1 A	<b>From:</b> 200601
<b>Model Year:</b> 2007	<b>Model:</b> Camry	<b>Doc ID:</b> RM000000T4X00GX
<b>Title:</b> 2GR-FE ENGINE MECHANICAL: ENGINE UNIT: DISASSEMBLY (2007 Camry)		

## **DISASSEMBLY**


### **1. REMOVE OIL FILLER CAP SUB-ASSEMBLY**

(a) Remove the oil filler cap and gasket.

### **2. REMOVE SPARK PLUG**


(a) Remove the spark plugs.

### **3. REMOVE OIL PAN DRAIN PLUG**




(a) Remove the drain plug and gasket.

### **4. REMOVE VENTILATION VALVE SUB-ASSEMBLY**



(a) Remove the ventilation valve.

### **5. REMOVE CAMSHAFT POSITION SENSOR**



(a) Remove the 4 bolts and 4 sensors.

